

Find hole in tube & roughen  
the surface around the  
hole with sand paper

Peel the layer off the patch  
and apply to hole

Press patch firmly onto tube  
and insert tube into the  
tire and re-inflate

Made in Taiwan