




HP/HV DUAL-SCALE GAUGE FLOOR PUMP

40/160PSI


CLEVER VALVE



GF-2232
40psi / 160psi


Switch High Volume and High Pressure mode by switch lever on handle top
Dual-Scale Gauge display for
Low pressure and High pressure

0~40psi zone: 1psi digit gap, special for
FAT tire, MTB and Gravel bike tire
40~160psi zone: Fit for Road bike tire
3" big gauge
Clever Valve: Automatically change for
Presta and Schrader




▲ Switch mode for High Volume and High Pressure

INSTRUCTION




▲ Clever Valve



Choose High Volume or High Pressure mode.



Insert pump head to tire valve.



Flip up the lever to securely hold the valve, then inflate.

(4) After inflating desired pressure, unlock the lever and take the pump head off the tire.

Made in Taiwan